
Update your satellite


Check to see if your firmware versions are the same for your Router and your Satellite(s). Do this from routerlogin.net

The user name is admin and the password is what you set up when you set up the account or it's on the bottom of your router.



If any of them are not the same, you will need to manually update the satellites individually.


Go to netgear.com/support/product and type in MS60 (since you are looking for the satellite firmware). Download the version you need. Probably 1.0.6.110



After it's done downloading, unzip it and save the .chk file to your computer so you can upload it.

Get the IP address for each satellite

My Router: Nighthawk MR60



Open a second browser and type in the IP address of your satellite. For the satellite in this screenshot I would use http://192.168.1.3

You will be prompted to use your routerlogin.net password.



The satellite will reboot and you will be able to see the updated firmware version from the status.

My Satellite: Nighthawk MS60

